

Power bank

instrukcja obsługi

Ten produkt nadaje się do urządzeń cyfrowych, które mają wejście DC-5V. Przeczytaj całą instrukcję.

Obsługa urządzenia

- 1、 Włącznik/wyłącznik: służy do włączania i wyłączenia urządzenia oraz do sprawdzania poziomu naładowania baterii.
- 2、 Wskaźnik poziomu baterii: służy do sprawdzania poziomu baterii. 4 świecące diody oznaczają, że power bank jest w pełni naładowany
- 3、 Wejście: używaj Micro USB, aby naładować power bank.
- 4、 Wyjście: power bank może zostać użyty do ładowania wszystkich urządzeń z wejściem DC-5V.



Uwaga: Jeśli power bank ma lampkę LED, w przeciągu 3s wciśnij dwukrotnie Włącznik aby włączyć/wyłączyć lampkę.

Jak naładować POWER BANK

- 1、 Podłącz power bank do komputera lub laptopa za pomocą kabla USB.
- 2、 Wskaźnik poziomu baterii będzie migał przy ładowaniu power banku
- 3、 Gdy power bank będzie w pełni naładowany, wskaźnik będzie się świecił, nie migał.



Uwaga: Power bank posiada zabezpieczenie, które wyłączy power bank w razie niepoprawnego użytkowania. Aby ponownie użyć power bank należy go ponownie naładować.

Wskaźnik baterii

zapalone diody	poziom naładowania
1	0-25%
2	26-50%
3	51-75%
4	76-100%

Jak używać power bank?

- 1、 Upewnij się, że urządzenie, którego używasz ma wyjście 5V.
- 2、 Użyj odpowiedniego kabla, aby połączyć power bank z urządzeniem, które chcesz naładować. Po połączeniu wciśnij przycisk "włącz" i ładowanie rozpocznie się.
- 3、 Rozłącz urządzenia po naładowaniu.

Power bank obsługuje większość urządzeń dostępnych na rynku, m.in.: tablety, PSP, MP3, MP4 itp.



UWAGA

- 1、 Przed pierwszym użyciem naładuj power bank w 100%
- 2、 Używaj odpowiednich kabli. Nieodpowiednie kable mogą uszkodzić power bank.
- 3、 Przed ładowaniem upewnij się, że wejście w urządzeniu, które chcesz naładować ma 5V.
- 4、 NIE uderzaj, NIE rzucaj, NIE rozbieraj na części power banku, NIE naprawiaj go samemu.
- 5、 Nie kładź power banku blisko urządzeń emitujących ciepło, ani w pobliżu łatwopalnego otoczenia.
- 6、 Nie wkładaj niczego (poza odpowiednim kablem) do gniazdek power banku. Może to doprowadzić do awaryjnego wyłączenia, bądź do uszkodzenia power banku.
- 7、 Conajmniej raz na 3 miesiące naładuj i rozładuj powerbank.

Najczęściej zadawane pytania

- 1、 Dlaczego power bank nie działa?
Sprawdź:
Czy kabel USB jest odpowiednio podłączony?
Czy power bank został włączony?
Czy w power banku jest odpowiednia ilość energii?
Czy ładowane urządzenie jest kompatybilne z power bankiem?
- 2、 Dlaczego ładowanie zostało przerwane i po naciśnięciu przycisku "włącz" rozpoczęło się od nowa?
Napięcie jest zbyt wysokie i power bank wyłączył się awaryjnie. Wciśnij przycisk "włącz" i rozpocznij ładowanie ponownie.
- 3、 Dlaczego power bank nie chce naładować innego urządzenia
Power bank jest kompatybilny jedynie z urządzeniami, które na wejściu mają DC-5V.
Urządzenie może nie być kompatybilne z power bankiem.

Importer

Importer:
AXPOL Trading sp. z o.o. sp. k.
ul. Krzemowa 3, Złotniki,
62-002 Suchy Las, Polska

Portable Power bank

User Manual

This product is applicable to digital products whose input is DC-5V. Please read the whole user manual.

Operating Instructions

- 1、 Power Switch: This button is used to turn on/off the power bank and to check the battery status.
- 2、 Battery Level Indicator: This button is used to check the battery level. All four lights are on means full battery.
- 3、 Input: Please use Micro USB to charge this power bank.
- 4、 Output: This power bank can charge all digital products with DC-5V input.



Instruction: If this power bank has LED flash light, please press power switch button twice within 3 seconds to turn on/off the light.

How to Charge This Power Bank?

- 1、 Connect this power bank to a computer or a laptop or a power adapter by a USB cable.
- 2、 The battery level indicator will be flashing when charging the power bank
- 3、 When fully charged, the battery level indicator is on, NOT flashing.



Notice: Short circuit protection can be caused by improper operation, which will then shut down the power bank. Please recharge the power bank to activate it.

Battery indicator

Battery Indicator	Battery Level
1 Light one	0%-25%
2 Light one	25%-50%
3 Light one	50%-75%
14Light one	75%-100%

How to Use This Power Bank?

- 1、 Please make sure the output of the digital device you are charging is 5V.
- 2、 Please use qualified USB cable to connect the power bank by the USB port and the other end to your digital device. Then press the power switch on the power bank and charging starts
- 3、 Please disconnect them when your device is full charged.

This power bank can support digital products such as most smart phones on the market, tablets, PSP,MP3, MP4 etc.



Notes:

- 1、 Please fully charge this power bank when using it for the first time
- 2、 Please use qualified cable and charger to charge the power bank. Or it could cause damage to the power bank.
- 3、 Before charging, please make sure the input voltage of your device is 5V.
- 4、 Do NOT beat or knock or disassemble this power bank, or try to repair it by yourself.
- 5、 Do NOT put this power bank near any heat source or in flammable environment.
- 6、 Please avoid damage caused by kids' misuse.
- 7、 Do not put any other objects in the input/output port of this power bank. It could lead to short circuit or damage.
- 8、 Please charge and discharge the power bank at least once per 3 months to activate it.

FAQ:

- 1、 Why is my power bank not working?
Please check:
Is the USB cable good and well connected?
Is the power switch on?
Is there enough electricity left in the power bank?
Is the device compatible to the power bank?
Is the power bank in short-circuit protection?
If yes, please recharge to activate it.
- 2、 Why the charging is interrupted and after I press the power switch, charging starts again?
Because the charging current is excessive. And the over current protection function is activated by it. Press the power switch to reboot and charging starts again.
Because the power bank is in short-circuit protection. Press the power switch to reboot and charging starts again
- 3、 Why can't my power bank charge this device?
This power bank is only applicable to digital products whose input is DC-5V.
Digital device has its charging specifications. It's not compatible with power bank.

Importer

Importer:
AXPOL Trading sp. z o.o. sp. k.
ul. Krzemowa 3, Złotniki,
62-002 Suchy Las, Polska